

PC specification :

OS : Linux Ubuntu V9.04

CPU : Intel Pentium 3.4GHz

RAM : 1GB


Download BT747 :

http://bt747.free.fr/content/?q=compatible_gps



BT747_1.68.5_full.rar

1. Open **BT747** software folder.
2. Execute **“run_j2se.sh”** file.
3. Select **“Output Setting”** page and **“language”**.



4. Select “**Log operations**” page.
5. Select “**com port**” and “**baudrate:38400**”, then push “**Connect**” button.
6. Download method select “**Normal download**”.
7. Select “**file format**” you want to convert, then push “**Convert To**” button.

